

## Standard Film for Vintage Polaroid Spectra™ Cameras

Polaroid Spectra cameras are wider than regular Polaroid cameras, so they need a different film. Spectra film gives you all the same tone and texture of our other film, with a wider frame. For when you absolutely, positively have to fit everybody in the shot.



### 8 Instant Photos

- [1] Film speed may vary, allow for +/- 1/4 stops
- [2] Do not freeze the film

- ☐ Classic white frame
- ☀ ASA 640<sup>[1]</sup>
- ☰ Photos develop in 5–10 mins
- ❄ Best stored refrigerated<sup>[2]</sup>

**Format**  
**Image Area**  
**Finish**  
**HS or HTS code**  
**PRD #**  
**EAN #**  
**Battery report (UN38.3)**  
**Warranty info**

4" x 4.1" (10.2 cm x 10.3 cm)  
3.5" x 2.9" (9 cm x 7.3 cm)  
Glossy  
37012000  
004679  
9120066087829  
Available  
[polaroidoriginals.com/warranty](http://polaroidoriginals.com/warranty)

### 8 Instant Photos

- [1] Film speed may vary, allow for +/- 1/4 stops
- [2] Do not freeze the film

- ☐ Classic white frame
- ☀ ASA 640<sup>[1]</sup>
- ☰ Photos develop in 10–15 mins
- ❄ Best stored refrigerated<sup>[2]</sup>

**Format**  
**Image Area**  
**Finish**  
**HS or HTS code**  
**PRD #**  
**EAN #**  
**Battery report (UN38.3)**  
**Warranty info**

4" x 4.1" (10.2 cm x 10.3 cm)  
3.5" x 2.9" (9 cm x 7.3 cm)  
Glossy  
37012000  
004678  
9120066087812  
Available  
[polaroidoriginals.com/warranty](http://polaroidoriginals.com/warranty)

### Store chilled, shoot warm

Temperature affects how the film works. Keep it stored cold in the fridge, but never freeze it. Ideally you should let it adjust to room temperature before you use it. That's around 55–82°F (13–28°C). When it's cold out, keep your photos warm in a pocket close to your body while they develop. Or if it's a hot day, make sure they stay cool.

### Shoot with the light

The more light in your shot, the better your photo will turn out. Instant film loves light, especially natural light. Use the flash for all your indoor photos. For best results we also recommend using the flash for outdoor shots, unless it's a bright sunny day.


### Develop in the dark

All photos appear blank at first. They're most sensitive during this time, so don't bend or shake them. Shield them from the light, and place them face down as they develop. Keep B&W photos shielded from light for about 1 minute, and color film for about 6 minutes.


### Care for your camera

Your camera has a set of rollers inside the film door. Each photo passes through these rollers as it's made, so it's important to make sure that they stay clean. If the rollers get visibly dirty then gently wipe them down with a soft, damp cloth.

### For use with:



Polaroid Spectra™



Polaroid Image™

### Does not work with:



new Polaroid  
i-Type cameras

Have a problem, or a question you need answered? **USA/Canada**  
[usa@polaroidoriginals.com](mailto:usa@polaroidoriginals.com)  
1-212-219-3254

**Contact our Customer Support Team** **EU/Rest of World**  
[service@polaroidoriginals.com](mailto:service@polaroidoriginals.com)  
00800 5770 1500

or visit [polaroidoriginals.com/help](http://polaroidoriginals.com/help)